

Указания за монтаж на артикула

Налични елементи

- А винт
- В шуруп
- С болт
- Д шуруп
- Е бленда
- Ж шуруп
- З шуруп
- И шуруп
- К шуруп
- Л шуруп
- М бленда
- Н рафт 2бр
- О бленда
- П шуруп
- Q шуруп
- Р врата
- W шуруп

Exploded view showing: М бленда, Н рафт 2бр, страница, N гръб, дъно, R врата, W шуруп.

1. Using a mallet, drive the bolt (C) into the pre-drilled hole in the side panel.

2. Tighten the bolt (C) with a screwdriver.

3. Drive the screw (W) into the pre-drilled hole in the side panel.

стъпка 1

Attach the back panel (N) to the side panels (M) using bolts (C). Then attach the top panel (E) and bottom panel (W) to the side panels (M) using screws (B) and (D).

стъпка 2

Attach the drawers (H) to the side panels (M) using screws (E). Attach the door (R) to the side panels (M) using hinges (P). Finally, attach the door (R) to the front panel (Q) using hinges (J).

Готово изделие
контейнер KN104

The final assembled product is a rectangular container with a door and two drawers, labeled as container KN104.