WESDAR

Геймърска оптична мишка X10
Инструкции за употреба

Thanks for Choosing WESDAR
We are offering you better Input Devices from now on.
Better Work Way's available since with WESDAR WIRED MOUSES
User Manual-X10 Wired Mouse

Specifications:

Main Material	ABS+Metal+braided wire
Light effect	Blue/Purple/Red/Green
Buttons	Left, right, scroll wheel, DPI, forward,backward
Tracking system	Optical
Sensor	702
Resolution	800/1200/1600/2400DPI
Port	USB
Cable Length	150cm
Operating Voltage	4.25V-5.25V
Rated Voltage / Current	DC 5V /≤100mA

Button Click Life	10 million times
Item size	132*70*42mm
Net Weight	138g

Features

High-end optical engine, precise positioning.

6 buttons, including scroll wheel, left button, right button, forward , backward, DPI switcher.


Adjustable 800/1200/1600/2400DPI.

Ergonomical design, comfortable touch, long-term use without fatigue.

Intelligent connectivity, plug and play.

Total 4 bright colors showing, giving you a colorful visual effect.

Suitable for high-end players, gaming professional players



1 Right button

2 .Left button

3 .Scroll wheel

4 Forward

5 .DPI switcher

Backward

Package Contents

Wired Mouse*1

User manual*1

System requirements

Windows 2000/Windows XP/Windows Vista/Windows 7/Windows 8/MAC

Setting up the Mouse

Plug the USB plug into an available USB port on your computer. Windows automatically finds your mouse and installs the appropriate driver.

Precautions

- A. Avoid using the mouse on surfaces of low surface finish such as clothing, newspapers, carpets, hardwoods, etc.
- B. Do not bump mouse.
- C. The mouse should not be moved in the box.
- D. Do not use the mouse in high temperature and strong light.
- E. Do not put the mouse into the liquid.
- F. Both light-emitting diode and light-sensitive three-tube in the optical mouse are afraid of being vibrated accessories, please avoid pulling the mouse in a strong way.
- G. Care should be taken to keep the plate clean and photosensitive state is good, to avoid dust attached to the light-emitting diodes and light-sensitive three-tube, and block the light received, affecting the normal use.
- H. Do not over-force the mouse button and avoid breaking the mouse, to avoid damage to the elastic switch or other components.

Warranty Card

Dear users, Thank you for purchasing WESDAR products, in order to provide better service, please read the user manual carefully after purchased. Please keep this warranty card. Though we're not willing to see this from our customer, you're welcome to contact us when you have any questions. We will provide services with pleasure. Read more on www.i-wesdar.com

Unauthorized removal or misuse of the user is not covered by the warranty

Customer Name	
Contact Information	
Contact Address	
Product Model	
Purchasing Date	
Order No.	
Purchasing Place	